

RECON

**HOW TO INSTALL 264124BK & 264124CL
Ford 2004-2008 F-150 LED 3rd BRAKE LIGHT**

*Prior to the installation of your RECON Ford F-150
LED 3rd Brake Light, please follow the instructions below.*

Mounting: '04-'08 F-150 3rd Brake Light:

Remove your factory 3rd brake light and disconnect the wires from the back of the three bulbs. The plug you need to connect your new RECON light is located back inside the vacant hole in your truck cab and is held in place with a small white clip. To locate the clip, look up and to the right into the hole left behind after removing your factory installed 3rd brake light. You will see the tip of the white clip protruding through a metal panel. Reach into the hole with a long, flat head screwdriver and press down on the clip until it pops out. Then you simply need to pull on the factory wires until you see the plug that matches your new RECON brake light. Connect the two plugs and re-use your factory screws to mount your brand new RECON LED 3rd brake light. DO NOT OVERTIGHTEN...remember you are screwing down into a plastic housing and care is needed to ensure a nice snug fit that isn't so tight that you crack the plastic housing.

**If you have any questions, feel free to contact us:
info@reconaccessories.com - www.GoRecon.com**