



Install Guide for RECON part 264519BK – Ford F150 LED Fog Light Kit

1. First you will need to remove two screws and one push pin from the splash shield directly behind the fog light.



2. Next, remove the adjustment screw from the bottom of the OEM fog light. When this is removed, the spring will also come off of the assembly. Save both the screw and spring for the installation of the new RECON fog light.
3. Unplug the wire harness from the OEM fog light and remove the bulb.
4. Remove the OEM fog light housing from the front of the bumper. We highly recommend using a plastic pry bar so you do not scratch the bumper housing when removing the light. You will need to pry the light out of the two retention holes by inserting the pry bar between the light and the housing. This will release the round pin on the light from the hole on each side. Start with the side on the inside of the truck with each light. See the pictures below.





5. Next, simply snap the RECON fog light into place and install it using the same steps as removing the OEM light.
6. Adjust the light as needed and enjoy your new RECON LED fog lights!!



-If you have any questions or concerns, please give us a call @ (877)377-3266
www.gorecon.com